Heat-Flo HF30 Buffer Tank with low mass wall hung boiler

Heat-Flo, Inc.

HF30BT Top connect buffer tank

Heat-Flo

6

DISCLAIMER

This drawing shows system piping concept only. Installer is responsible for all equipment and detailing required by local codes. Size header piping for maximum flow velocity of 2 feet/ second. All other piping should be sized for a maximum flow velocity of 4 feet/ second. Install a minimum of 12 diameters of straight pipe upstream of all circulators and check valves. Install isolating flanges or isolating valves on all circulators. Install purging valve(s) on all circuits. All closely spaced tees shall be within 4 pipe diameter center to center spacing. Install minimum of 6 pipe diameters of straight pipe upstream and downstream of all closely spaced tees. Differential pressure bypass valve prevents flow noise under partial load conditions (some zone valves closed). Set differential pressure bypass valve to delta P of distribution system with all zones open +1 psi.

Heat-Flo, Inc.



DIMENSIONS & CAPACITIES

MODEL	Storage Volume		Dimensions (Inches)			Piping Connections	Max. Tank Working Pressure	Approx. Shipping Wt.
	(Gal.)	A(Ht.)	В	c	D (Dia.)		(psi)	
HF-30-BT	30	34.0	-	-	23.5	1 1/4"	60	77

Nipple from

TOP

Dip Tube to

BOTTOM

½ x F from TOP

Nipple from

TOP

Dip Tube to

BOTTOM

DISCLAIMER

This drawing shows system piping concept only. Installer is responsible for all equipment and detailing required by local codes. Size header piping for maximum flow velocity of 2 feet/ second. All other piping should be sized for a maximum flow velocity of 4 feet/ second. Install a minimum of 12 diameters of straight pipe upstream of all circulators and check valves. Install isolating flanges or isolating valves on all circulators. Install purging valve(s) on all circuits. All closely spaced tees shall be within 4 pipe diameter center to center spacing. Install minimum of 6 pipe diameters of straight pipe upstream and downstream of all closely spaced tees. Differential pressure bypass valve prevents flow noise under partial load conditions (some zone valves closed). Set differential pressure bypass valve to delta P of distribution system with all zones open +1 psi.